

Online optical measurements in hot gas flow


Sønnik Clausen

Senior Scientist


sqcl@kt.dtu.du




Large scale flame



Leak valve bottle



Ship engine




Exhaust air craft engine

Optical measurements at DTU KT \square



Laboratory & Full scale

- Gas temperature
- Gas composition
- Gas velocity and mixing
- Particle concentration and size
- Thermal heat exchange, spectral emissivity
- Fuel properties, burning value
- Imaging
- Your application?






Optical measurement principles





 Passive measurement (no active light source, one port)



 Absorption measurement (light source, two ports)

$$I = I_0 e^{-abc}$$







Spectral range 120 nm – 250 μm

UV: NO, SO₂, KCI, OH, tar, ...

IR: H_2O , CO, CO_2 , C_xH_y , HCI, SO_3 ,...






Optical measurements



IR-sensor Ch1

- Fast measurements
- Non-intrusive measurement
- Insight into process
- Work successfully in lab and full scale
- High-end and low cost instruments
- More accurate measurements
- No calibration using modern methods and database
- Remote measurements
- Work in LT gasifiers (tar, high dust load)
- Many parameters at the same time
- Wide range of applications




LDA probe

⁴ DTU Chemical Engineering, Technical University of Denmark


LDA FLOW MEASUREMENTS








Flow measurement Pyroneer (LT)













Particle size and velocity







Double 70 ns pulsed LED, $\Delta t = 1 \mu s$



DTU Chemical Engineering, Technical University of Denmark




Sprays, droplet size and velocity

Giovanni: oil spray

Morten Søe: spray

Coating: erosion

Water jet 48 mm from nozzle




Velocity principles:

Imaging (dual pulse, high speed)

Laser (LDA)


Correlation






Simple optical sensors

- Monitor parameters of interest
- Improving process
- New opportunities



- Fast response
- Innovation
- Output 4 20 mA
- Store data in data base






9 DTU Chemical Engineering, Technical University of Denmark



Gas temperature




Methods: Suction pyrometers (TC), FTIR (intensity), UV (shape features)

Burner region.

Red: snap-shot,


Black: running average over 40 s





TIME CONSTANT GAS TEMPERATURE

Practical boiler measurements



Measurement of flue gas temperature with IR-thermometer, thermocouple (TC) and suction pyrometer. Approx. 5 minutes delay on TC measurement.




IR Gas Measurement

A gas has an unique finger print

Dipole: H₂O, CO, CO₂, CH₄, HCl, ...


No IR spectrum: N₂, O₂, H₂, ...

Non-linear triatomic molecule





Hot Gas Cell Facilities at DTU




Temperature range: 23 ° C – 1600 ° C

Pressure range: 0 – 200 bar

UV, VIS, IR, FAR,...

Validation of CO₂ and H₂O Radiative Properties






Paper: International Journal of Greenhouse Gas Control, Jan. 17, 2011


UV NO detection



 λ =215 nm absorption band: DT= DT_{rot} \pm 50°C



but signal drop by approx. a factor 10 due to broadering of gas bands.




Paper: In-situ Gas temperature measurements by UV-absorption spectroscopy



Comparison Measurement and Model

Example hot gas cell versus Hitemp




CALIBRATION FREE GAS CONCENTRATION MEASUREMENT

CO Concentration




Cross stack Measurement of CO Straw Fired Grate





FTIR and UV Spectroscopy - probes










DTU

Snap-shot spectra






Incoming radiation: 160-242 kW/m² (±1 sigma)

Theory – Principles On-line Gas Analysis






(1)
$$L_{m}(\lambda) = \varepsilon(\lambda, T_{g,c_{i}}) L(\lambda, T_{g}) + \tau(\lambda, T_{g,c_{i}}) L(\lambda, T_{w})$$

(2a)
$$\varepsilon(\lambda, T_{g,c_i}) = \alpha(\lambda, T_{g,c_i}),$$
 (2b) $\widetilde{v} = \frac{1}{\lambda}$

(3)
$$\alpha(\lambda, T_g) = \frac{L_m(\lambda) - L(\lambda, T_w)}{L(\lambda, T_g) - L(\lambda, T_w)}$$

IR Gas Analysis






Emission spectrum:

GB: 816.9°C, ε =0.106


Blackbody curve at 836.0°C

Transmittance spectrum CO₂, H₂O, CO, C_xH_y, ...





Ex.1: FTIR Fiber Optic Flame Measurements




1600 BR43, Blok1 19. Dec. 2007 RISØ DTU 20000 - 0.4 20000 - 0.3 20000 - 0.2 20000 - 0.2 20000 - 0.1 20000 - 0.2 20000 - 0.1 20000 - 0.2 20000 - 0.1 20000 - 0.2 20000 - 0.1 20000 - 0.2 20000 - 0.1 20000 - 0.2 20000 - 0.1 20000 - 0.2 20000 - 0.1 20000 - 0.2 20000 - 0.1 20000 - 0.2 20000 - 0.1 20000 - 0.2 20000 - 0.1 20

Measurements close to wall


Measurements in Flame


CO follow particle concentration and typical in an on/off mode (poor mixing)



Optical versus Extractive








On-line corrosive Monitoring System

- FTIR: CO, CO₂, H₂O, HCI, ...
- UV: SO₂, metals, KCl, ...



LONG TERM MEASUREMENTS for years






Corrosive and dust loaded hot gas




NO problems?







UV SPECTROSCOPY














Low cost soot and tar sensor

Patented principle: fast signal of soot and tar for regulation




HWAM wood stove





Instruments and sensors



Raspberry Pi (30 EUR) + DTU board



Summary

- Optical measurements powerful tool
- Wide range of parameters can be measured (welcome to contact me about specific topics)
- Mobile instrumentation for large scale
- Good performance
- Deep insight into process and physics
- Work in corrosive, hot and difficult applications (like gasifiers)
- 30 years experience in the field at DTU
- DTU is open for cooperation






Questions?

Mail: sqcl@kt.dtu.dk

Phone: +45 20814523



DTU Chemical Engineering

Department of Chemical and Biochemical Engineering